GAME ADJUSTMENT CHART

BANK A		SW1	SW2	SW3
TIME ADJUST	25 SEC	OFF	OFF	OFF
	30 SEC	ON	OFF	OFF
	35 SEC	OFF	ON	OFF
	40 SEC	ON	ON	OFF
	45 SEC	OFF	OFF	ON
	50 SEC	ON	OFF	ON
	55 SEC	OFF	ON	ON
	60 SEC	ON	ON	ON

SHOT COUNT	SW4	SW5
20 SHOTS	OFF	OFF
22 SHOTS	ON	OFF
25 SHOTS	OFF	ON
30 SHOTS	ON	ON

COIN ADJUST	SW6	SW7
1 COIN/1 CREDIT	OFF	OFF
2 COINS/1 CREDIT	ON	OFF
3 COINS/1 CREDIT	OFF	ON
FREEPLAY	ON	ON

TICKET SOUND	SW8
NORMAL	OFF
TICKET SOUNDS OFF	ON